

## 23ZERO Kabari XL & 3.0 AWNING BRACKET KIT



1. Slide in two of the channel nuts. One in the top channel, one in the lower in desired awning bracket position. Optional: Slide an additional channel nut in the underside channel.



2. Align your bracket with the channel nuts and insert the washer first, then the M8 bolts in line with the nuts



3. Using a 5mm Allen key tighten the nuts, you can use the existing holes in the brackets to make the process easier.

## 23ZERO Kabari XL & 3.0 EXTENDED WINDOW POLE MOUNT



1. Remove existing window fly bracket from the tent.



2. Once removed, leave the existing channel nuts in the original spot.



3. Using (2) M8 bolts, place the raised window fly plate into the channel nuts ensuring the backing plate is attached on inside.



4. Using a 5mm Allen key, tighten the bolts.



5. Place the new window fly bracket into the top holes, make sure plate is facing the correct way.



6. This process will need to be repeated on all 4 existing window fly brackets to account for awing.