



WOOF-DEN

USER MANUAL




23 ZERO
2195 S Presidents Dr, Suite B,
West Valley City, UT 84120 USA
WWW.23ZERO.COM
Ph: (855) 875 7755
E: info@23ZERO.com


1. Lay out WOOF-DEN and peg out outer corners



2. Lay out poles and identify




3. Assemble body poles x 2



- 4.** Identify front of swag (canopy end). Insert Pole A over pin & rings and attach top 2 clips only.



- 5.** Repeat for pole B rear of swag



- 6.** Insert ridgepole in holes provided on body poles and tighten using trigger lock. Attach remaining clips.



7. Insert ridgepole extender into pole A



8. Attach canopy strap to ridgepole extender and tension.

WARNING: Do not over tension as this will cause pole failure




9. Set up complete



Repeat previous steps in reverse to pack down WOOF-DEN

- 1.** Lay WOOF-DEN flat and fold in half



- 2.** Place poles in pole bag, position on edge of fold.



- 3.** Roll WOOF-DEN



- 4.** When fully rolled, WOOF-DEN should fit comfortably in carry bag.





2195 S Presidents Dr, Suite B,
West Valley City, UT 84120 USA
WWW.23ZERO.COM
Ph: (855) 875 7755
E: info@23ZERO.com